



FIGURE 2: TRADITIONAL BOLTED TRUSSES FOR SUPPORTING PROFILED METAL ROOFS: DIAGRAM SHOWING THE REQUIRED TOP AND BOTTOM CHORDS, AS WELL AS WEBS, AND ALSO ALL CONNECTING DETAILS. DETAILS ARE SUPPLIED FOR A RANGE OF SLOPES OF ROOF AS WELL AS A RANGE OF ROOF SPANS (DISTANCE BETWEEN ROOF SUPPORTS). THE TRUSSES SHOWN HERE CAN BE ERECTED AT A MAXIMUM OF 1050 MM APART.